



ENGLISH

LG265 Quick Reference Guide

Some of content in this user guide may be different from your phone depending on the software of the phone or your service provider. Features and specifications might be subject to change without prior notice.



Bluetooth QD ID B014981

Visit http://calgservice.com/index_b2c.jsp for the User Guide fully illustrated on how to use your phone.

P/N: MSAB0030501 (1.1)H

Getting Started With Your Phone

Installing the Battery

1. Remove the battery cover by sliding it upward. Align the battery with the terminals near the bottom of the phone. Align the battery cover then slide it downward until it clicks into place.



Removing the Battery

1. Turn off the phone, then push the battery cover from down to up such as shown below.
2. While holding the battery cover, lift and remove the battery cover.
3. Lift the top of the battery out using the fingertip cutouts, then remove it.

Charging the Battery

Warning!

Use only the charger provided with the phone. Using any charger other than the one included with the LG265 may damage your phone or battery.

1. Plug the end of the adapter into the phone's charger port and the other end into an electrical outlet.
2. The charge time varies depending upon the battery level.



Notice
Triangle symbol should face down.

Phone Overview



Receiving Calls

1. When the phone rings or vibrates press **CALL** to answer a call.
Note
If you press **CALL** or **END CALL** the side keys while the phone is ringing, the ringing or vibration is muted for that call.
2. Press **END CALL** to end the call.

Bluetooth®

The LG265 is compatible with devices that support the Bluetooth® headset and hands-free profile(s). You may create and store 20 pairings within the LG265 and connect to one device at a time. The approximate communication range for Bluetooth® wireless technology is up to 30 feet (10 meters).

Notes

- Read user guide of each Bluetooth accessory that you are trying to pair with your phone because the instructions may be different.
- The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license. Other trademarks and trade names are those of their respective owners.
- Your phone is based on the Bluetooth® specification, but it is not guaranteed to work with all devices enabled with Bluetooth® wireless technology.

Entering Text With the QWERTY® Keyboard

Your phone features a slide-out QWERTY keyboard, specifically designed for easy and comfortable text entry. The QWERTY keyboard uses the same layout and works just like the keyboard on your computer. The easiest way to enter text is using your thumbs to type on the QWERTY keyboard.



To enter text with the QWERTY keyboard:

1. In a text entry screen, slide open the QWERTY keyboard. (The display automatically adjusts to landscape mode.)
2. Use your thumbs to enter text.
 - To change capitalization, press **SHIFT**.
 - To enter alternate characters on a key, press **FN** and then press the key. To lock the function key (as when entering a series of numbers), press **FN** twice.
 - To enter symbols, press **SYM** and select a symbol.
 - For additional text entry options, including Symbols and 123, press Left Soft Key and select an option.

Menus Overview

1. Call History 1. View	5. Missed Alerts 1. View	*. My Downloads Tools Ringers Screensavers Games Memory Card Memory Status
2. Messages 1. Send Message 2. Text Message 3. Email 4. IM 5. Facebook 6. Picture Message 7. Web Alerts 8. Voicemail 9. Settings	6. IM 1. Launch IM	0. Media Player 1. Launch
3. Bluetooth 1. Pair with Hands Free 2. Send a Contact 3. Send Files 4. Add a New... 5. Trusted Devices 6. More...	7. Photos 1. Camera 2. Photo Album 3. Picture Message 4. Print 5. Settings & Info	#. Tools 1. GPS Nav 2. Memory Card Manager 3. Alarm Clock 4. Scheduler 5. World Clock 6. USB Mode 7. Calculator 8. Voice Control 9. Voice Memo *. Notepad 0. Utilities #. Update Phone
4. Contacts 1. Contacts Listing 2. Backup	8. Web 1. Launch	
9. Settings 1. Display 2. Sounds 3. Airplane/Music Mode 4. Bluetooth 5. Messages 6. Keyguard 7. Text Entry 8. Phone Support 9. More...		

Menu Access
To use phone menus, press **CALL** using Navigation Key to highlight and select. Press the number key that corresponds to the submenu.

Bluetooth Menu 3

The LG265 is compatible with devices that support the Bluetooth® headset and hands-free profile(s). You may create and store 20 pairings within the LG265 and connect to one device at a time. The approximate communication range for Bluetooth® wireless technology is up to 30 feet (10 meters).

Pair with Hands Free/ Send a Contact/ Send Files/ Add a New.../ Trusted Devices/ More...

Contacts Menu 4

The Contacts Menu allows you to store names, phone numbers and other information in your phone's memory. When you access your Contacts, the number in parentheses represents the number of entries you have stored (up to 600).

Contacts Listing/ Backup

Missed Alerts Menu 5

Displays the list of your missed alerts. This feature allows you to check out functions you have not promptly checked. For example, the features are Missed Calls, Alarm, Text Messages.

IM Menu 6

Allows you to log on to specific web messaging services and chat online. Privacy policy and charges may vary.

Photos Menu 7

Your phone's built-in camera gives you the ability to take full-color digital pictures, view your pictures using the phone's display, and instantly send them to family and friends.

Camera
Taking pictures with your phone's built-in camera is as simple as choosing a subject, pointing the lens, and pressing a button. You can activate the phone's camera mode whether the phone is open or closed.

Photo Album
Your phone's picture storage area is called Photo Album. There are three types of folders that can be used separately according to your needs:
In Phone/ Memory Card/ Online Albums.

Picture Message
Allows you to store your picture messages.

Print
Pictures in your phone and memory card can be printed via the connection between your phone and a printer. While the transfer, you cannot receive incoming calls and you need printer setting to use this menu.

Settings & Info
The Settings menu allows you to configure where pictures are saved, view your account information, or switch the format between portrait or landscape mode.

Web Menu 8

The Web feature allows you to view Internet content especially designed for the mobile phone interface. For specific information on Web access through your phone, contact your service provider.

- Send and receive Internet e-mail.
- Browse and search the World Wide Web via web pages especially designed for wireless phone customers.
- Set bookmarks to directly access your favorite sites.
- Retrieve information, such as stock quotes and flight schedules from the Internet.

Settings Menu 9

The Settings Menu has options to customize your phone.

Display/ Sounds/ Airplane/Music Mode/ Bluetooth/ Messages/ Keyguard+/ Text Entry/ Phone Support/ More...

* The Auto Keyguard setting applies only when the flip is closed.

My Downloads Menu *

You have access to a dynamic variety of Premium Service content such as downloadable Games, Ringers, Screensavers, and other applications.

Note Additional fees may apply.

Turning the Phone On and Off

Turning the Phone On

1. Install a charged battery or connect the phone to an external power source.
2. Press **POWER** for a few seconds until the LCD screen lights up.

Turning the Phone Off

1. Press and hold **POWER** until the display turns off.

Making Calls

1. Make sure the phone is turned on. If not, press **POWER** for about 3 seconds.
2. Enter the phone number (include the area code if needed).
3. Press **CALL**. If the phone is locked, enter the lock code.

Notes

- By default, the lock code/password is the last 4 digits of your phone number. You can change this code/password in Security menu.
- If the phone is restricted, you can only dial phone numbers saved in the Emergency Numbers or your Contacts. To turn off this function: **CALL** -> **Settings** -> **More...** -> **Restrict and Lock** -> **Limit Calls** -> **Outgoing Calls** -> **Unlock** -> **CALL**
- Press **END CALL** to end the call.

How to Use Menus

This section provides a quick glance of features on your phone.

Call History Menu 1

The Calls Menu is a list of the last phone numbers or Contact entries for calls you placed, accepted, or missed. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Messages Menu 2

Send Message
Allows you to send text messages, picture messages, pages, and e-mail transmissions. Each message has a destination (up to 25 recipients per message) and information (Message). These are dependent upon the type of message you want to send.

Text Message
Text Messages are grouped by senders/receivers with date.

Email
You can get your corporate email, synchronize your contacts, and have access to your company's directory.

IM
Allows you to log on to specific web messaging services and chat online. Privacy policy and charges may vary.

Facebook
With Bell Mobile Browser, you can enjoy community service.

Picture Message
Allows you to store the received picture messages in a separate folder.

Web Alerts
Allows you to store the received web messages in a separate folder.

Voicemail
Allows you to view new voice messages recorded in the voicemail box. Your phone will alert you when you receive a new voice message.

Settings
Allows you to configure 8 settings for messages.
Notification/ Callback Number/ Signature/ Quick Messages/ Auto-Delete/ Message Reminder/ Edit Voicemail #/ Web Alerts

My Downloads Menu * (Continued)

Tools
To download an available Tools to your phone.

Ringers
To download an available Ringers to your phone.

Screensavers
To download an available Screensavers to your phone.

Games
To download available Games to your phone.

Memory Card
Up to 16GB is supported. It allows you to easily store images, music, and voice data in your phone.

Memory Status
Displays the used and available memory space.

Media Player Menu 0

Your phone's built-in media player gives you the ability to listen to your own personal MP3s right from your phone's display.

Tools Menu

GPS Nav/ Memory Card Manager/ Alarm Clock/ Scheduler/ World Clock/ USB Mode*/ Calculator/ Voice Control/ Voice Memo/ Notepad/ Utilities/ Update Phone

* When you connect your phone to a PC with USB cable, the phone screen displays USB Mode menu allowing you to enter Mass Storage, Phone As Modem or Print.

